



SPOT GEN4™

クイックスタートガイド

QUICK START GUIDE • GUIDE DE DÉMARRAGE RAPIDE
GUÍA DE INICIO RÁPIDO • GUIA DE INÍCIO RÁPIDO •
GUIDA RAPIDA • KURZANLEITUNG • SNEĽSTARTGIDS
GUIDE TIL HURTIGSTART • HURTIGSTARTVEILEDNING
SKRÓCONA INSTRUKCJA OBSŁUGI • SNABBSTARTSGUIDE


SPOT GEN4 クイックスタートガイド



SPOT Gen4は、SPOTサービスプランへの加入が必要です
S.O.S.機能はサービスプランへの加入が必要です

1 シリアル番号(ESN)と認証コードの表示位置

シリアル番号と認証コードは、SPOT Gen4本体のバッテリーケース内にあります。
FindMeSPOT.com/Activateでユーザーアカウントを登録する際に、これらのコードが必要になります。



2 ユーザーアカウント登録とファームウェアの更新

1. 新しいSPOT Gen4端末のユーザー登録:

[FindMeSPOT.com/Activate](https://findmespot.com/activate)

- **NEW SPOT CUSTOMERS:**
Select **Begin Activation**.
- **EXISTING SPOT CUSTOMERS:**
Login using username & password.

2. Follow onscreen instructions to complete activation.
3. Configure your profile via SPOT My Account.
4. Download the SPOT Updater:
[FindMeSPOT.com/SPOTGen4Support](https://findmespot.com/spotgen4support)
5. Follow onscreen instructions to update firmware and sync.

For more information on how to use your new device, refer to the SPOT Gen4 User Guide located at: [FindMeSPOT.com/SPOTXGen4UserGuide](https://findmespot.com/spotxgen4userguide)

3 LED/BUTTON TEST - TEST BEFORE EVERY ADVENTURE

Device check: Insert fresh batteries* and then perform the LED/Button test.


1	With your SPOT Gen4 off, press & hold the Track button followed by the Power button . Hold for approximately 3 seconds.	The HELP and S.O.S. LEDs should turn green.
2	Press the S.O.S. and Help buttons at the same time.	All LEDs should turn red.
3	Press the Custom Message and Check In buttons at the same time.	All LEDs should turn green.

NOTE: Steps have to be performed within a few seconds of each other, or the test will timeout. You can start over if the test is not completed.

4 TEST YOUR SPOT GEN4



1. Go outside where there is a clear view of the sky and no obstructions.
2. Power on.
3. Orient SPOT Gen4 so that the SPOT logo is facing up toward the sky.
4. Press and hold the button until the function light blinks green. To ensure delivery, leave active for 20 minutes.
5. Verify receipt of your message in SPOT Mapping and by your friends and family.



*Power options:

- 4 AAA Energizer® Ultimate Lithium 8x batteries (L92)
- 4 AAA Energizer® NiMH rechargeable batteries (NH12)